



1) Unscrew the shaft to required length. Remove the aluminum cover.



2) Insert the stretch film roll and aluminum cover, and then tighten the shaft.



3) Wrap your object.